HIGH ALTITUDE ENROUTE CHART - ICAO CURAÇAO FIR

RNAV 5 required

COMMUNICATION

Curaçao Control	124.1/127.1
Curaçao Terminal	119.8
Hato Curaçao International Airport (TNCC):	
TWR	118.3
ATIS	132.6
Flamingo International Airport (TNCB):	
TWR	118.7
ATIS	132.3
International Reina Beatrix Airport (TNCA):	
APP	120.9
TWR	118.0
ATIS	132.1

SPECIAL USE AIRSPACE

TND - 5 SFC - 10000* Naval air exercises
TND - 6 SFC - 27000* Gunnery/missile firing
* by NOTAM
All other special use airspace is identified on the Area Charts for Curaçao/Bonaire and Aruba

NOTES

- ABA VOR declination 11°W
- PJB VOR declination 12° W
- PJG VOR declination 12° W
- Altitudes, elevations in feet, distances in nautical miles, bearings are magnetic.

LEGEND

- 11°W Isogonic line
- Area Chart Area chart boundary
- On-demand reporting fix
- Compulsory reporting fix
- Fly-by on-demand reporting wpt
- Fly-over on-demand reporting wpt
- Fly-by compulsory reporting wpt
- Fly-over compulsory reporting wpt

CHANGES: Curaçao TMA airspace and callsign