

1. Pilots should request RNP approach on first contact with Beatrix tower.
2. Straight-in heights are relative to THR elevation, all other heights are relative to AD elevation
3. Visual descent point (VDP) is where LNAV OCA intersects 3° descent slope.
4. Altitudes, elevations and heights in feet, distances in nautical miles, bearings are magnetic.