


MAXIMUM WIND SPEED CHART

JUANCHO YRAUSQUIN APT
SABA

WIND SPEED LIMITATIONS FOR SABA

- 1. Landing is prohibited when wind speed exceeds the limites noted below.
- 2. The chief pilot or his designated representative must give PRIOR approval before any landing is attempted when winds exceed these limits, i.e. emergencies.



NOTE: Diagram is oriented using degrees true, wind bearings are labeled using degrees magnetic.

CHANGES: New chart.